


72-140 Removal and installation of arm rest with grip

Removal


1 Detach and remove liner.




2 Remove screw in recess.



3 Remove top grip screw.



4 Unscrew both arm rest screws and take arm rest off of door liner.



Installation

5 Install in reverse sequence.